



# FUN FORTRESS PLAYHOME

Assembly Instructions

P.O. Box 3054  
City of Industry CA 91744  
T: 626.333.4222  
E: info@asweets.com  
www.wonderandwise.com

## Parts:

A 7 pcs 985 mm


A1 2 pcs 985 mm

A2 2 pcs 985 mm


B 4 pcs 865 mm

C 6 pcs 665 mm


D 4 pcs 250 mm




E x4




F x6



G x12



H x1 pc



I x2 pcs



fabric cover  
J x2 pcs



K x2 pc



### WARNING!

Adult assembly recommended. Discard all packaging after assembly. Keep away from fire.



### AVERTISSEMENT!


Montage de l'article à effectuer par un adulte.  
Retirer tous les emballages avant de donner le jouet à votre enfant.  
Les détails et coloris du contenu peuvent varier. Informations à conserver. Attention! Tenir loin du feu!




### ADVERTENCIA!

El montaje debe ser realizado por un adulto.  
Retire todo el embalaje antes de dar el juguete al niño. Los detalles y los colores pueden ser diferentes de los contenidos. Por favor guarde las instrucciones. Atención! Mantener lejos del fuego!


## Step 1




## Step 2




## Step 3




Step 4




Step 5




Step 6



Step 7



Step 8



Step 9

