



WONDER & WISE
BY ASWEETS GLOBAL INC.
P.O. Box 3054, City of Industry CA 91744
wonderandwise.com


MADE IN CHINA

    @wonderandwise



Little Wood Baby Chair

Assembly Instructions



WARNING:
Keep away from flame.
Adult supervision recommended.
Assembly by an adult.

P.O. Box 3054
City of Industry CA 91744
T: 626.333.4222
E: info@asweets.com
www.wonderandwise.com

Designed in USA Made in China

• **Never leave child unattended.**

Always keep child in view while in Little Wood Baby Chair.

• Ages 5m+ or use only with infant who can hold up their head unaided or can sit up unassisted. Do not use with children over 26.5 lbs (12kg) or over 30 inches (76cm).

• Never use near stairs, stoves or ovens, fireplaces, heaters, swimming pools or other dangerous areas.

• Always place Little Wood Baby Chair on a flat surface. For use on floors only. Do not place Little Wood Baby Chair on tables, chairs or counters.

• Ensure that the child is correctly and safely positioned in the seat with the crotch restraint carefully fitted and connected. The straps should fit snugly against child.

• Strings can cause strangulation! DO NOT place items with a string around child's neck, such as hood strings or pacifier cords. DO NOT suspend strings over product or attach strings to toys.

• Be aware of the danger of allowing other children to play near the product.

• Recommended time limit per use session is 20 minutes.

• Do not use this product if it is damaged or broken. Throw away at first sign of damage or weakness.

• Only replacement parts supplied by the manufacturer should be used on the product.

• Remove and discard all packaging materials properly before use.

Cleaning & Care:


Wood surfaces: wipe with mild soap and water. Air dry.

Silicone tray cover: can go into dish washer or wash by hand.


Fabric cushion: machine wash cold, gentle cycle. No bleach. Dry Flat. Do not iron. Do not dry clean.




Parts:




Step 1




Step 3




Step 2




Step 4




Step 5




Step 6




Step 7




Turn the screws into the threaded inserts on both sides. Adjust the tray forward or backward to fit your child, and tighten the screws securely in place.



Step 8




Step 10




Adjust the position of the Velcro on side straps to fit child.

Step 9




Step 11




Without silicone tray liner, attach interchangeable activity toys to Velcro tabs.

Features:



Chair can be used without tray by attaching linkable rings and rattles (not included) to center bar.



Toys can be placed in back storage area when not in use.